

**TO OPEN THE BOX, PLEASE GENTLY TENT THE UPPERMOST FLAP,
WHICH WILL RELEASE THE OTHER FLAPS**



**TO COLLAPSE THE BOX, INVERT IT AND TENT THE BOTTOM FLAPS
AS SHOWN BELOW AND THE BOX WILL THEN FOLD FLAT**

